




NON PRINTING



DIELINE



GRID
UNITS

UV COATING: NOT OK

UV上光: 不行

FOIL STAMP: NOT OK

烫金: 不行


FILM LAMINATION: NOT OK

覆膜: 不行

WATER-BASE GLOSS VARNISH: OK

水性亮油: 行

ALL COLOURS PRINT CMYK 全部以四色印刷



Black
C:0 M:0
Y:0 K:100

DATE:
02.07.2026

PRODUCT CODE:
43-771-424

FILE NAME:
FOLDING BENCH TROLLEY
LOCATION & OPERATOR:
HENG FENG

BACK COVER
14.85cm

FRONT COVER
14.85cm

anko

Folding Bench Trolley Assembly Instruction & User Manual




MADE IN CHINA
CUSTOMER SERVICE:
KMART AU: 1800 124 125
KMART NZ: 0800 945 995
TARGET AU: 1300 753 567

THE UMBRELLA SHOULD BE ALWAYS INSERT INTO SAND OR
GRASS DURING USAGE

KEYCODE: 43-771-424

PARTS LIST



- A.Cart
- B.Pillow x 2
- C.Front wheel with brake x 2
- D.Rear wheel x 2
- E.Hand Knob x 2
- F.Umbrella
- G.Ground Pole
- H.Carrybag

Take all accessories out.

ASSEMBLY INSTRUCTION



1. Locate the cart frame and 4 wheels. Lay cart frame sideways on a non-abrasive surface. Insert rear wheel by pushing into frame, screw the hand knob.


2. Assemble front wheel by pushing into frame until it clicks into place.
Tip: When disassembling, the wheel can be released by pressing the button.



3. Pull apart the ends of the frame. Finish by pushing in the middle of the bed until the frame is fully extended.



4. To fold the cart, start by pulling up on the webbing loop in the middle of the cart bed. Next, push the front and rear ends of the frame toward the center.

	NON PRINTING  DIELINE  GRID UNITS	UV COATING: NOT OK UV上光: 不行 FOIL STAMP: NOT OK 烫金:不行 FILM LAMINATION: NOT OK 覆膜:不行 WATER-BASE GLOSS VARNISH: OK 水性亮油: 行	ALL COLOURS PRINT CMYK 全部以四色印刷  Black C:0 M:0 Y:0 K:100	DATE: 02.07.2026 PRODUCT CODE: 43-771-424 FILE NAME: FOLDING BENCH TROLLEY LOCATION & OPERATOR: HENG FENG
Anko Styleguide Artwork				

BACK COVER
14.85cm

FRONT COVER
14.85cm

anko

USER DIRECTIONS



1. Open the cart, attach two pillows, and secure them with Velcro.
2. Release the hook-and-loop tab on the side of the cart, and pull open the side zipper.
3. Lock the 2 front wheels by pushing down on the brake. Before sitting, please make sure the wheels can't move.



4. It is now ready to be used as a bench.
Tip: Don't forget to unlock the brakes by pulling up if you need to change back to cart mode.
5. Fully open the umbrella, attach the ground pole to the umbrella shaft, then hold the handle, insert the stake pole of sunshade umbrella into the sand and rotate downwards until it reaches the safety sticker. Insert the umbrella pole through the webbing loop on the rear of the cart to install the sunshade umbrella.
Warning: Pack sand firmly around the pole to ensure stability.



6. It is now ready to be used as a bench with sunshade umbrella.
Tip: Don't forget to unlock the brakes by pulling up if you need to change back to cart mode.
7. Detach the umbrella shaft from the ground pole, pull out the stake pole from sand, then fold the umbrella and place both parts into the carry bag. Use the side carrying straps to transport the folded umbrella conveniently.

WARNING!

Adult assembly required. Keep removable hardware away from children.
Keep away from fire and flames.
Keep children away from the cart during folding&unfolding.
Do not allow children or pets in cart while in motion.
This product is designed for storing and transporting only. Do not carry passengers while moving.
The umbrella is designed for insertion into soil or sand only. Do not use on flat ground.

CARE INSTRUCTIONS:

Wipe clean with a damp cloth.
Do not use bleach, acid or solvents on the item.
Ensure product is completely dry before storing away.
Do not leave outside when not in use, store in a dry and level place.