

折叠尺寸80x106mm 双面印刷风琴折
128g双面铜板纸

<div data-bbox="371 331 632 422"></div> <div data-bbox="371 438 637 470"><p>Instruction Manual</p></div> <div data-bbox="335 506 671 894"></div> <div data-bbox="362 917 644 968"><p>Bluetooth® Headphone K: 43-787-906 T: 73-071-907</p></div> <div data-bbox="442 982 567 1001"><p>Made in China</p></div> <div data-bbox="349 1014 657 1047"><p>Before use please read this manual carefully. Please retain for future use.</p></div>	<div data-bbox="841 327 1154 359"><p>Battery Safety Warnings</p></div> <div data-bbox="841 371 1388 810"><p>1. Do not expose the battery to extremely high or low temperatures during use, storage, or transportation, nor to low air pressure at high altitudes.</p><p>2. Do not replace the battery with an incorrect type, as this may compromise the device's safety protection (especially for lithium batteries).</p><p>3. Never dispose of the battery in fire or a hot oven, or mechanically crush or cut the battery, as this may cause an explosion.</p><p>4. Do not leave the battery in extremely high-temperature environments, which may cause explosion or leakage of flammable liquid or gas.</p><p>5. A battery exposed to extremely low air pressure may cause explosion or leakage of flammable liquid or gas.</p><p>6. This product is only compatible a adapter with 5V/1A for power supply.</p></div> <div data-bbox="845 846 1163 869"><p>Sensitivity: 100dB +/- 3dB at 1kHz</p></div> <div data-bbox="845 884 1376 1026"><p>Warning: Excessive sound pressure from headphones can cause hearing damage. Avoid prolonged listening at highvolume levels.</p><p>This product is an audio accessory. This product is not a toy and is intended for use by consumers aged 12 years and older.</p></div>	<div data-bbox="1465 331 1694 359"><p>Product Overview</p></div> <div data-bbox="1526 375 1900 753"></div> <div data-bbox="1460 798 1750 827"><p>Description of all parts</p></div> <div data-bbox="1465 835 1943 1037"><p>1. Volume up or Next song 2. Power on/off or Pause/Play or Calling/Answer 3. Volume down or previous song 4. Voice Assistant Button 5. Microphone hole 6. USB-C charging port 7. Indicator light 8. 3.5mm audio input</p></div>
<div data-bbox="233 1205 464 1234"><p>Package Contents</p></div> <div data-bbox="233 1247 503 1348"><p>Bluetooth® headphone x1 USB-C charging cable x1 Instruction manual x1 3.5mm audio input cable x1</p></div> <div data-bbox="233 1386 521 1415"><p>Product Specifications</p></div> <div data-bbox="233 1428 752 1646"><p>Bluetooth® Connection: HP_Headphones Bluetooth® Transmission Distance: About 10m Input: 5V 500mA Headphone Battery: 3.7V, 300mAh, 1.11Wh Bare Weight of Product: About 178g Charging Time: Approx 2 hours Playing Time: Approx 15 hours (80% volume play music) Cable: USB-C charging cable Speaker x 2: 32Ω 10mW</p></div> <div data-bbox="233 1682 542 1711"><p>Bluetooth® Pairing Steps</p></div> <div data-bbox="233 1732 775 1900"><p>1. Press the for 2 seconds to power on, it automatically enters Bluetooth pairing mode. (The indicator light flashes alternately red and blue).</p><p>2. Navigate to Bluetooth settings on your device, locate the device name "HP_Headphones" and complete pairing. The indicator light will turn off once connection succeeds.</p></div>	<div data-bbox="841 1205 1027 1234"><p>Product Usage</p></div> <div data-bbox="841 1251 1383 1761"><p>1. Power on: Press and hold the for about 2 seconds, the indicator light flashes alternately red and blue.</p><p>2. Power off: Press and hold for about 2 seconds, the indicator light flashes red, the indicator light will turn off.</p><p>3. Answer a call: when a call is coming in, answer the call by pressing once, press again to hang up.</p><p>4. Reject a call : Press and hold for about 2 seconds.</p><p>5. Redialing the last number: Double click button.</p><p>6. Volume"+" and next song: Press and hold for next song, Press quickly volume up.</p><p>7. Volume "-" and previous song: Press and hold for previous song, Press quickly volume down.</p><p>8. Play / Pause music: when you listen to the music, you can play or pause the song by pressing button.</p><p>9. Wired connection: insert one end of the supplied 3.5mm audio cable into the headset's 3.5mm audio input jack, and the other end into a compatible device.</p><p>10. Charging port with USB-C charging cable.</p><p>11. Press and hold the Voice Assistant Button for 2 seconds to wake up the voice assistant.</p></div>	<div data-bbox="1444 1205 1694 1234"><p>12 Month Warranty:</p></div> <div data-bbox="1444 1247 1666 1264"><p>Thank you for your purchase.</p></div> <div data-bbox="1444 1278 1984 1398"><p>Your new product is warrantied to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law. For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.</p></div> <div data-bbox="1444 1413 1984 1516"><p>We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.</p></div> <div data-bbox="1444 1530 1984 1617"><p>Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.</p></div> <div data-bbox="1444 1631 1984 1734"><p>Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.</p></div> <div data-bbox="1533 1751 1644 1770"><p>MADE IN CHINA</p></div> <div data-bbox="1444 1782 1510 1864"></div> <div data-bbox="1533 1782 1710 1864"><p>CUSTOMER SERVICE: KMART AU: 1800 124 125 KMART NZ: 0800 945 995 TARGET AU: 1300 753 567</p></div> <div data-bbox="1444 1885 1984 1942"><p>The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth® SIG, Inc., and any use of such marks by KMART AUSTRALIA is under licence.</p></div>