


© Disney

MINNIE MOUSE DELUXE PRAM SET

K:43-796-182



Safety Notes


WARNING: CHOKING HAZARD - Small parts, not suitable for children under 3 years.
CAUTION: This item is a toy and should only be used with dolls. Not suitable for babies, children or pets. Assembly and disassembly must be carried out by adults only. Please check condition of item regularly, discontinue use of the item if excessive wear and tear is found. Keep these details for further reference. For safety reasons, remove all tags, labels and plastic fasteners before giving this toy to your child. Product may vary slightly from image shown.

Care Notes

This fabric should not be machine-washed. Please wipe clean using a damp cloth with mild detergent if necessary.

MADE IN CHINA

Part Lists




1 X Main body frame 1X Canopy 4 X Wheels


Assembly

<div>1.</div> <div>Lift the handle to release the chassis (A) from the folded position.</div>	<div>2.</div> <div>The rings will engage automatically when unfolded.</div>	<div>3.</div> <div>Insert the plastic locks on both left and right sides into the pipe.</div>
<div>4.</div> <div>Insert each of the wheel (C) into the pipe until you hear a "click". Give each wheel a firm pull to ensure they are securely attached.</div>	<div>5.</div>	

6. Slide the connectors into the left and right sides.




7.




Close the doll pram

1. Fold down the sunshade.



2. Release the plastic locks and rings.



3.

