Assembly Instructions

K: 43712229/T: 72440063 Silicone Accessory Kit

ATTACHMENT INSTRUCTION: Suitable for Smooth tile, shiny marble, glass, or mirrors. Not suitable for: Timber/wood, matte textured tiles, undulated tiles, leather, painted or unpainted drywall/plasterboard, over grout lines, or mosaic tiles.

Thoroughly clean the surface and allow it to dry. Peel off the backing film. Carefully stick the product to the surface, ensuring it is level Press firmly for 30 seconds and wait 24 hours before use.



Ax1	Bx1	Cx2
		

Step 1 : Clean the surface.



Step 2 : Remove the backing protective film.







Step 4: Press the backing firmly on the wall.



Step 5: Wait for 24 hours before use.



REMOVAL: Can be removed with hair dryer, heat the tape for 3-5 minutes to make it warm, then remove residual with methylated spirits.