anko

Cat Scratcher Cupcake Tower

Contents

1  1PC SIZE 595mm*395mm*15mm	2  1PC SIZE 485mm*265mm*15mm	3 1PC SIZE 285mm*285mm*15mm	4 1PC SIZE 280mm*280mm*12mm
5 1PC SIZE 235mm*200mm*15mm	6 1PC SIZE 298mm*298mm*12mm	7 3PCS SIZE L=215mm	8 1PC SIZE L=230mm
9 2PCS SIZE L=300mm	10 1PC SIZE L=300mm	11  1PC	12 1PC



Accessory	Size	Quantity
A	8mm*35mm	9pcs
B	8mm*80mm	2pcs
C	8mm*25mm	1pc
	5mm	1pc

Assembly Instructions

Step 1.

Using the Hex key and screws (A x 6) connect screw poles (No.7 x 3) and boards (No.3 x 1 & No.4 x 1). Place the cupcake cover (No.12) over the assembled boards and poles.



Step 2.

Using the Hex key and screw (C x 1), screw the cupcake house (No.12 x 1) on board No.1. Then using the Hex key and screw (A x 1), screw the pole (No.8 x 1) on board No.1. For pole placement please refer to the image below.



Step 3.

Insert the screw (B x 1) into pole No.8. Attach the board (No.5 x 1) on screw B. Screw pole (No.9 x 1) onto screw B. Using the Hex key and screw (A x 1) screw pole (No. 9 x 1) with the cupcake house No.12. For pole placement please refer to the image below.



Step 4.

Insert the screw (B x 1) on pole No.9. Attach the board (No.2 x 1) on screw B. Screw pole (No.10 x 1) on screw B. Using the Hex key and screw (A X 1) screw board (No.2 x 1) together with the pole (No.9 x 1). Then screw board (No.6 x 1) with pole No.10. Place the top cover No.11 onto board No.6. See below image.



WARNING:

For your pet's safety, inspect regularly and remove if damaged.

Always supervise your pet during play.