


# INSTRUCTIONS

This manual is applicable to following type of products: 99010.

## OPERATION GUIDE



- The fixing piece for chassis can be used to twist the lock of the battery cover. See picture 1.

- Please open the lid and put 5 X 1.5V "AA" batteries into the car according to its polarity, then close the lid and twist the chassis piece to lock the battery cover. See picture 1.

- Please open the lid and put the 2 X 1.5V "AA" batteries into the controller according to its polarity, then close the lid and twist the chassis piece to lock the battery cover. See picture 1.

- Every time before playing, the transmitter needs to pair with the model car as follows:

- ◆ The LED indicator on the transmitter will blink and ready for pairing. Switch on the model car, the LED on the transmitter will go out. This means the pairing process is completed. Then the model car can be fully controlled by the transmitter. See picture 3.



- Adjust the direction adjustment switch to control the car running in a straight line.

- Please replace battery when LED indicator becomes dark which means low battery.

- The speed of model car will slow down when battery is low. Please replace then.


- 2.4GHZ transmitters are compatible to control several model cars at same time without interference, provided that the pairing process is orderly done one by one following above steps. That is, first transmitter finishes pairing with first model car and keep their power on, then second transmitter can begin to pair with second model car...

- Please turn off the model car after playing.




## FEATURES & FUNCTION

This product uses 2.4GHz communication technology, which is compatible for multi-device and multi-user, with fast response speed, high response precision, and strong anti-interference capability.




BATTERY






DIRECTION  
ADJUSTMENT

BATTERY  
ON-OFF  
SWITCH



Function: forward, reverse, turn left, turn right, with sound, headlights, rear lights, the doors on both sides and the front hood and trunk can be opened manually.

Features: Authentic car styling with injection moulded body, independent suspension system.



Picture for reference only, subject to actual product.

## CAUTION

- Different types of batteries or new and used batteries are not to be mixed. Exhausted batteries are to be removed from the toy.
- Batteries should be replaced by an adult. Batteries are to be inserted with the correct polarity. The supply terminals are not to be short-circuited.
- Non-rechargeable batteries are not to be recharged. Rechargeable batteries are to be removed from the toy before being charged. Batteries are to be charged by an adult or by children at least 8 years old, leaked or broken batteries are not to be charged.
- Rechargeable batteries are only to be charged under adult supervision.
- Only batteries of the same or equivalent type are recommended to be used.
- The wire, USB wire or battery plug are not to be inserted into output socket.
- Never put the batteries near fire or any source of heat, water or direct sunlight.
- Skin or clothing is to be washed immediately if you make contact with leaked liquid from the battery.
- For better preservation of rechargeable batteries, please regularly recharge them, and only a charger of the same or equivalent type is recommended to be used.
- Dispose of batteries responsibly, do not dispose of in fire.


- When your vehicle starts to lose power, it may lose its functions or performance. This indicates that it's time to refresh your batteries or recharge them.




- Don't play your vehicle through sand, water or snow.




- Point your transmitter antenna up not down toward your vehicle. If your vehicle gets too far away, it won't work properly. If your transmitter has an antenna carry-loop feature, make sure the antenna is removed from the holder and straightened before operating.



- Radio interference can make your vehicle run badly. Interference can be caused by other radio control vehicles running on the same frequency, electrical wires, large buildings, or CB radios. Try to stay away from them! It is prohibited to drive your vehicle in any dangerous area.



- Don't put your vehicle near heat or in direct sunlight. Always turn switches OFF after operating.



## MAINTENANCE

- Remove the batteries when the unit is not in use for long periods.
- Clean the vehicle with a soft cloth.
- Never put the batteries near fire or direct sunlight.
- Keep dry.
- Regularly examine the toy for any damage to its wires, plug, enclosure and other parts and they must not be used until the damage has been repaired.



**R-NZ**

Frequency bands: 2400MHz to 2483.5MHz

Maximum Transmitting Power (EIRP) : Not more than 10mW.



**WARNING:**

CHOKING HAZARD-Small parts.  
Not for children under 3 years.

The instruction has to be kept since it contains important information.

**RASTAR GROUP**

Add: Xinghui Industrial Park, Xiadao Road, Shanghua,  
Chenghai, Shantou, Guangdong, China.

[Http://www.rastar.com](http://www.rastar.com)