




Alarm Clock manual

Using the Alarm Clock:

Insert the 3 x AAA batteries into the battery compartment inside the back of the clock. Ensure the polarity of the batteries match the polarity inside the battery compartment.



1. Hour/Month button
2. Min/Date/°F/°C Button
3. Snooze/Light button
4. Years/ "12/24" hour button
5. Alarm/Time/Date setting switch
6. Alarm On/Off Switch
7. Light sensor On/Off switch
8. Battery cover

Time setting:

- a. Switch (5) to "TIME SET" position,
- b. Press " HOUR", "MIN" to set the time,
- c. Once Time is set, please switch (5) to "LOCK" position.

Alarm setting:

- a. Switch (5) to "AL SET" position,
- b. Press " HOUR", "MIN" to set the time,
- c. Once Alarm time is set, please switch (5) to "LOCK" position.

Date setting:

- a. Switch (5) to "DATE SET" position,
- b. Press " YEAR", "MONTH" and "DATE" to set the DATE,
- c. Once Date is set, please switch (5) to "LOCK" position.

12/24 hour display setting:

Switch between "12/24" hour format by pressing the "12/24" button. Once the display is set in 12 hour mode, AM and PM will show up on the display.

Snooze and light function

When the alarm sound is ringing, press the "SNOOZE/LIGHT" button (3), the alarm sound will stop and ring again every 5 minutes until alarm switch to "AL OFF" position.

Light sensor function:

Once the "SENSOR" button is switched to the ON position, the LCD display will automatically adjust the screen brightness according to the light in the surrounding area.
To turn this function off, please switch the "SENSOR" button to the OFF position.

12 Month Warranty

Thank you for your purchase from Kmart.

Kmart Australia Ltd warrants your new product to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law.

Kmart will provide you with your choice of a refund, repair or exchange (where possible) for this product if it becomes defective within the warranty period. Kmart will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre on **1800 124 125 (Australia)** or **0800 945 995 (New Zealand)** or alternatively, via email at **customer.satisfaction@kmart.com.au** for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to our Customer Service Centre at 690 Springvale Rd, Mulgrave Vic 3170.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.