


- For better preservation of rechargeable batteries, please regularly recharge them, and only a charger of the same or equivalent type is recommended to be used.
- Dispose of batteries responsibly, do not dispose of in fire.
- Alkaline batteries or rechargeable batteries are suitable for this product.

• When your vehicle starts to lose power, it may lose its functions or performance. This indicates that it's time to refresh your batteries or recharge them.




• Do not operate your car on the streets where people gather or under high voltage wires. Stay safe!



• Don't drive your vehicle in sand, through water or snow.



• Don't put your vehicle near heat or in direct sunlight. Always turn switches OFF after operating.



• Point the antenna of the remote control upward to the car, and control the car within the effective range, so as not to affect the play effect.



Picture for reference only, subject to actual product.

## MAINTENANCE

- Remove the batteries when the unit is not in use for long periods of time.
- Clean the vehicle with a soft cloth.
- Avoid being heated or being exposed to strong sunlight.
- Keep dry.
- Regularly examine the toy for any damage to its wires, plug, enclosure and other parts. They must not be used until the damage has been repaired.

**RASTAR**



# INSTRUCTIONS

This manual is applicable to the following types of product: 53800,98500,93300,93400,94800,10450.



**R-NZ**

Frequency bands: 2400MHz to 2483.5MHz  
Maximum Transmitting Power (EIRP) : Not more than 10mW.




**WARNING:**  
CHOKING HAZARD-Small parts.  
Not for children under 3 years.

The instruction has to be kept since it contains important information.

## RASTAR GROUP

Add: Xinghui Industrial Park, Xiadao Road, Shanghai, Chenghai, Shantou, Guangdong, China.  
Http://www.rastar.com  
Email: toysinfo@rastar.com


## OPERATION GUIDE





- Tools should be used for opening the battery cover, Screwdriver can be used to twist the lock of the battery cover, See picture 1.
- Please open the lid and put 3 X 1.5V "AA" batteries into the car according to its polarity, then close the lid and twist the chassis piece to lock the battery cover.
- Please open the lid and put the 2 X 1.5V "AA" batteries into the controller according to its polarity, then close the lid and rotate the knob to lock the battery cover. See picture 1.
- Every time before playing, the transmitter needs to pair with the model car as follows:
  - ◆ The LED indicator on the transmitter will blink when ready for pairing. Switch on the model car, the LED on the transmitter will go off. This means the pairing process is completed. Then the model car can be fully controlled by the transmitter. See picture 3.
- Adjust the direction adjustment switch to control the car running in a straight line.
- Please replace battery when LED indicator becomes dark which means low battery.
- The speed of model car will slow down when battery is low. Please replace.
- 2.4GHz transmitters are able to control several model cars at same time without interference, provided that the pairing process is completed in order. That is, first transmitter finishes pairing with first model car and keep their power on, then second transmitter can begin to pair with second model car.
- Please turn off the model car after playing.

## FEATURES & FUNCTION

This product uses 2.4GHz communication technology, which is compatible with multi-device and multi-user, with fast response speed, high response precision, and strong anti-interference capability.



Function: Forward, Reverse, Turn Left, Turn Right.  
Features: Authentic car styling with injection moulded body, independent suspension system.



## CAUTION

- Different types of batteries or new and used batteries are not to be mixed. Exhausted batteries are to be removed from the toy.
- Batteries should be replaced by an adult. Batteries are to be inserted with the correct polarity. The supply terminals are not to be short-circuited.
- Non-rechargeable batteries are not to be recharged. Rechargeable batteries are to be removed from the toy before being charged.
- Rechargeable batteries are only to be charged under adult supervision. Leaked or broken batteries are not to be charged.
- Only batteries of the same or equivalent type are recommended to be used.
- Never put the batteries near fire or any source of heat, water or direct sunlight.
- Skin or clothing is to be washed immediately if you make contact with leaked liquid from the battery.