


Summertime Picnic Table Instruction Manual

2-5
years


Parts List



A. Table top
x 1pc




B. Seat Panels
x 2pcs




C. Side Panels
x 2pcs

Assembly Instruction


Step 1: Open the hinge locks as shown.




Step 2: Snap the Side Panel (C) into the slots in Seat Panel (B) and Table Top (A) respectively as shown. Make sure it is firmly locked.




Step 3: Pull the Side Panel (C) along the slot. This will secure the side panels in place for locking.



Step 4: Close all the Hinge Locks on Table Top (A) and Seat Panel (B). Make sure all 8 hinge locks are both securely locked.




Step 5: Picture shows the completely assembled product.




Storage Instruction

Step 1: Turn the table upside down and lay down on the ground. Press 2 flaps and release the hinge locks.




Step 2: Press both side panels inward and detach the table top (A).



Step 3: Fold the Side Panel (C) as shown.

Step 4: Place the table top on the frame and lock into the ribs as shown.

Step 5: Picture shows completely assembled product for storage.



Warning

1. This product is designed for family domestic use only. Suitable for indoor and outdoor use.
2. Adult assembly required. No tools required.
3. Adult supervision required when item is in use.
4. When temperature falls below 0°C, outdoor use of this product is not recommended. In extreme cold, plastic materials lose resilience and may become brittle and crack upon impact. Remove and store product indoor.
5. When the picnic table is exposed to direct sunlight, check the temperature on the product surface. If the picnic table is too hot, pour cold water on the table until it cools and wipe dry before giving it to children.
6. Maximum weight limit is 46 kg per side or 23 kg per child. Limit 2 children per side.
7. DO NOT sit or stand on the table top.
8. Make sure all parts are securely snapped together before use.
9. Please check the unit twice monthly during the season it's being used, for tightness, and tighten as required. It is important that this procedure be followed at the beginning of each season. Replace as needed. If not checked regularly, parts can become loosened or misplaced and components can get detached and cause injuries.
10. DO NOT leave this item exposed to strong wind and inclement weather.
11. Choking hazard small parts, not suitable for children under 3 years prior to assembly.

KEEP THESE INSTRUCTIONS FOR FUTURE REFERENCE.

43-681-815

MADE IN CHINA

CUSTOMER SERVICE:

KMART AU: 1800 124 125

KMART NZ: 0800 945 995

TARGET AU: 1300 753 567