

BABY BALANCE BIKE INSTRUCTIONS

Keycode: 43419326

WARNING! Assembly by an adult.

WARNING! Suitable for children of 18-36 months old, due to danger of falling.

WARNING! Protective equipment should be worn.

WARNING! Not suitable for children with a body mass of more than 20 kg.

WARNING! Do not use on public roads.

WARNING! This toy has no brake.

Remove the balance bike and all the parts from the box. Set out all the parts and read the assembly instructions prior to use. Keep the packaging until assembly is complete.

General instructions

- This balance bike must be assembled by a responsible adult. Prior to use, make sure that the balance bike has been assembled properly. Remove all the parts which are not necessary for play before giving the balance bike to your child. Due to the skill it requires, the balance bike must be used with care in order to avoid falls or collisions likely to injure the user or others.
- To be used with suitable protective equipment, including a helmet, shoes, elbow, wrist and knee protection. Teach the child how to use it safely and responsibly.
- The balance bike is not a toy for children under the age of 18 months or over the age of 36 months.

Directions

- a) This product is not a road vehicle and should be used for leisure purposes only.
- b) For use on smooth, paved surfaces only. Avoid pot holes and bumps which could cause a child to lose control of the balance bike.
- c) Do not allow a child to ride this bike at dusk, at night or at times of limited visibility.
- d) Do not allow a child to ride this bike on roadways, public highways or alleys.
- e) Do not allow a child to ride this bike on steeply sloped areas.
- f) Do not allow a child to ride this bike near steps, swimming pools or other bodies of water.
- g) Do not allow a child to ride without shoes.
- h) Do not allow a child to ride in very loose clothing which could become entangled in the wheels.
- i) Be sure the rider keeps both hands on the handlebar for proper control.

- j) Max user weight 20kg. For use by 1 person at a time. Never ride with more than one person.
- k) If used indoors, ensure the ride on bike is not used near stoves, heaters, ironing boards or any other hot or dangerous objects.
- l) Avoid bumping into furniture, doors and walls to avoid damage and injury.

Before and after use

Check the balance bike before use for loose components and re-tighten where necessary.

Make sure all clamps and locking mechanisms are securely fastened.

Replace worn or broken parts immediately.


Check that wheels are securely attached and that wheels are rolling freely.

During use

Standing on the ground, place one foot on either side of the ride on bike.

Place one hand on each handle and push forward with feet.

Assembly Instructions:





top plastic cover



bottom plastic cover

IMPORTANT: The top&bottom plastic cover should be pre-assembled on the main frame. If not, please refer to above image and assemble. Then following below steps to assemble the balance bike.

Step 1: Insert the front wheels into the main frame tube.

Step 2: Remove the nut and bolt from the handlebar stem (tool for assembly provided). Place the handlebar stem into the main frame tube onto the front wheel stem.

Step 3: Align the holes in the handle bar stem with the holes in the front wheel stem. Fasten with the nut and bolt and tighten securely (tool for assembly provided). Push the clamp cover down to until it clicks into place and locks, covering the nut and bolt.

MADE IN CHINA

CUSTOMER SERVICE

KMART AU: 1800 124 125

KMART NZ: 0800 945 995

TARGET AU: 1300 753 567