


CAMILLE ENTERTAINMENT UNIT

Instruction Manual



The photos and illustrations shown in this instruction manual are generic.
The manufacturer reserves the right to change any specification or feature without prior notice.

IMPORTANT: KEEP FOR FUTURE REFERENCE. READ CAREFULLY.

Assembly Instructions



43488605/43683307/43709663 CAMILLE ENTERTAINMENT UNIT

CARE INSTRUCTIONS: WIPE CLEAN WITH A SOFT DAMP CLOTH. NEVER USE SCOURERS, ABRASIVES OR CHEMICAL SOLVENTS. KEEP AWAY FROM MOISTURE AND DIRECT SUNLIGHT. STORE IN A DRY PLACE. FOR INDOOR USE ONLY.









WARNING: DO NOT STAND, SIT OR LEAN ON THE UNIT. DO NOT USE THIS UNIT AS A STEP LADDER. ENSURE THIS UNIT IS USED ONLY ON A FLAT SURFACE. DO NOT USE THIS UNIT UNLESS ALL BOLTS AND SCREWS ARE FIRMLY SECURED. DO NOT PLACE HOT OBJECTS SUCH AS COFFEE CUPS DIRECTLY ON THE SURFACE OF THIS FURNITURE ITEM. THIS ITEM IS FOR STORAGE PURPOSES ONLY. CONTAINS SMALL PARTS. IT IS TO BE ASSEMBLED BY AN ADULT. FAILURE TO FOLLOW THESE WARNINGS COULD RESULT IN SERIOUS INJURY.

MAXIMUM SAFE LOAD: 25KG FOR TOP, 5KG FOR EACH SHELF.


1 Hardware List

A		6×30mm	25pcs	B		7×40mm	5pcs	C		3.5×12mm	24pcs
D		6×35mm	20pcs	E		15×10mm	20pcs	F		4×25mm	2pcs
G			4pcs	H		M4	1pc	I			2pcs
J		4×40mm	6pcs	K			1pc	L			4pcs
M		3×14mm	4pcs	N			4pcs				
O	   						2sets				


2 Parts List

							
①	1pc	②	1pc	③	1pc	④	1pc
							
⑤	1pc	⑥	1pc	⑦	1pc	⑧	1pc
							
⑨	1pc	⑩	2pcs	⑪	2pcs		

PANEL LAYOUT




STEP1




D -  × 4

STEP2




E -  × 4
A -  × 4

STEP3




A -		x 1
B -		x 1
K -		x 1
H -		x 1

STEP4




A -		x 4
B -		x 4
H -		x 1

STEP5




A -		× 4
J -		× 6

STEP6




D -		× 8
-----	---	-----


STEP7



STEP8




STEP9




D -  x 8

STEP10




E -  x 8
A -  x 8

STEP11




STEP12




C - **x 16**

STEP13

M -  × 4	L -  × 4
O -   × 2	



⚠ WARNING




Children have died from furniture tipover.

- NEVER allow children to stand, climb or hang on drawers, doors, or shelves.
- ALWAYS secure your television with an anchor device or mount the television on a wall.

This is a permanent label.
Do not remove!

STEP14

O -   × 2



TOPPLING FURNITURE WARNING:

- **ALWAYS** secure it with an anchor device.
- Please seek professional advice if you are in doubt of what fixing device to use.
- Regularly check that anchors are securely maintained.
- Use safety drawer locks to prevent children climbing.
- Stability of tall items may be affected by thick pile carpet or uneven floors .
- Do not place unanchored televisions on furniture .

CAUTION: for your safety when attaching the anchor fixings, please note the following:

- Check any electrical wires or plumbing inside the wall before drilling any holes (if you are unsure please seek professional advice from a qualified tradesperson).



WARNING: PLEASE SECURE YOUR FURNITURE WITH THE SUPPLIED WALL FIXING. SCAN THE CODE FOR MORE INFORMATION.

