## 30cm Balance Bike

Keycode: 43297832 Instruction Manual



## No Pedal Training Bicycle

- built with strong carbon steel
- rear caliper brake
- adjustable saddle and handlebar
- widened and wear-resistant pneumatic tire
- maximum loading weight: 25kg
- lightweight bicycle: 4.1kg

WARNING: ITEM TO BE ASSEMBLED BY ADULT ONLY. CHOKING HAZARD. CONTAINS SMALL ASSEMBLY COMPONENTS WITH FUNCTIONAL SHARP POINTS AND EDGES.

WARNING! PROTECTIVE EQUIPMENT SHOULD BE WORN. NOT FOR CHILDREN WITH A BODY MASS OF MORE THAN 25 KG, DO NOT USE ON WET SURFACES, UNEVEN OR UNPAVED ROAD. DO NOT USE ON PUBLIC ROADS OR IN TRAFIC. USE ONLY UNDER ADULT SUPERVISION.

## 30cm Balance Bike

- Please Assemble As Instructions -



Step 1: Insert the front fork (without front and rear distinction)



Step 3: Insert handlebar into fork tube, and tighten the screw with hex key as Pic 1, then put down the T bar cap as Pic 2, please note align handlebar and wheels



Step 2: Replace the clamp onto top of fork tube



Step 4: Insert seat, then tighten the screw of clamp under the seat



If necessary, use the wrench to adjust the screws of brake



Spare part

## **WARNING**

- ★ please check clamp bolts for tightness before riding.
- ★ The seat tube and the handlebar steerer tube must be inserted until the minimum insertion line indicated on tube is covered.