


SMART TAG

User manual



K: 43587292 | T: 71268248

MODEL: KMTSMT3BK

MADE IN CHINA

CUSTOMER SERVICE:

KMART AU: 1800 124 125

KMART NZ: 0800 945 995


TARGET AU: 1300 753 567

Before using your Smart Tag

Please read the manual thoroughly and keep it for future reference. The Smart Tag is compatible with the Find Hub app on your Android Phone. Once the tag is paired to your phone, the tag can be located via the Find Hub App on your phone or via a web browser on your compatible PC or Tablet. The Find Hub network requires Android phones with OS 9 and above. It is recommend to keep your devices' software regularly updated. Check Google Play for updates.

Setting up Smart Tag

- 1 Ensure your Android™ phone has the Find Hub app installed and Bluetooth is on.
- 2 Press and hold Function button to turn on the Smart Tag. If the Smart Tag doesn't turn on, charge it first following the instructions in this manual.



Pairing the device

- 1 Open the Find Hub app on your device. If you don't have the app installed, download it on Google Play or scan the QR code provided at the end of this manual to install it.
- 2 Wait until the Smart Tag appears on the search screen. Make sure the tag is close to your device for pairing. (Note: Ensure only one Smart Tag is present and in pairing mode to connect each time.)
- 3 Tap 'Connect' when the Smart Tag appears on the screen.




If the smart tag does not show on the device you are trying to pair it to after a couple of attempts, resetting the tag may assist (see resetting instructions on page 9).

- 4 Tap 'Done' to complete set up.

Once the smart Tag is linked, it will appear in the device list.

- 5 Tap the Smart Tag in the list to see the location and use other functions.



Finding items at close range

Select your paired Smart Tag in the Find Hub app and select 'Play Sound' to play a sound on the Smart Tag.

This function helps you locate items easily.

Playing sound only works when the Smart Tag is near your device (up to 20m in open space).

Enable Lost Mode

- 1 Select your paired item in the Find Hub app.
- 2 Select 'Mark as lost'.
- 3 Follow the prompts to add your contact information.

The option becomes available only when the Smart Tag is not near your paired Android device. When the Smart Tag is in Lost Mode, you'll automatically receive a notification when it's detected by other devices in Find Hub network.

Removing the Smart Tag

- 1 Select your paired item in the Find Hub app.
- 2 Tap on the gear symbol to see more options.
- 3 Select "Remove from Find Hub" at the bottom of the screen.

After the Smart Tag is removed, it will go into idle mode. Turn it off and on again if you want to pair the smart Tag again.

You will need to reset the Smart Tag if you are connecting it to a different device.

To reset the Smart Tag, refer to the resetting instructions on page 9.

Charging your Smart Tag

Type-C output end cable charging, charging power up to 0.45W.

The product supports charging with a 5V/1A charger.

Only use the supplied cable to charge the smart tags.


Please use a compliant charger, as fast charging may cause damage to the product.

Open the protective sleeve of the smart tag charging port and insert the Type-C charging cable as shown in the figure.

The red light turns on during charging, the light will turn off when the tag is fully charged.

Full charge takes approximately 3 hours.

Up to 4-month battery life. Actual usage time may vary depending on conditions. To ensure uninterrupted use, please charge the tag regularly.



Battery Status:

The Battery indicator icon will appear in the Find Hub app when you are on the connected Tag's app information.

The Find Hub app performs a battery level check hourly to update its power stage display. Restarting the device will also refresh the battery status.



Battery OK



Low battery



Very low battery

Using Other Functions

1. Turning on the Smart Tag

Press and hold the Function Button. The Smart Tag will play a melody and LED will flash.

2. Checking connection status

Double-press the Function Button. The Smart Tag will play a melody if it is linked to a device but not connected. The Smart Tag will beep if it's connected to an Android device.

In all cases, the light will flash. If the Smart Tag is not linked to any device, it will play a melody without the light flashing. The Smart Tag will not respond if it is turned off.

3. Activating Pairing Mode

If the smart Tag is not paired for 10 minutes, it will leave Pairing Mode. Press the Function Button once to enter Paring Mode again, the tag will beep and the light will flash.

4. Checking a lost Smart Tag's contact information

If you find a lost Smart Tag, you can use your Android phone to help return it to its owner. Turn on Bluetooth on your Android phone and open Find Hub app to scan the Smart Tag. The app will detect the lost device and display the owner's contact information.

5. Turning off the Smart Tag

Press the Function Button quickly five times. The Smart Tag will play a melody and the light will flash before turning off.

6. Resetting the Smart Tag

Quick-press the Function button 4 times, a beep or melody will play and the light will flash; then long-press and continue to hold the Function Button until a high pitch melody plays. (Note there may be additional beeping prior to the high-pitch melody depending on the Tag's status). This should be done in a single sequence. The tag is now reset.

Resetting the Smart Tag will disconnect any paired device. You will need to pair and connect to your device again to locate the Smart Tag.



Scan the QR code for a simple video guide.

FAQ:

1. What is Find Hub network? And how does it work?

Find Hub network provides an easy, secure way to locate compatible personal items on a map using the Find Hub app on your Android phone.

Simply pair your compatible product with Find Hub app to view it right alongside your devices. If your item ever goes missing, you can put it in Lost Mode to display a message and contact information to anyone who might find it. The Find Hub network is encrypted and anonymous, so no one else, not even Google, can view its location.

2. When can the device be located?

When a linked item is not with you or lost, it can be found by other Android devices that are part of Find Hub network.

3. How does the device discourage unwanted tracking?

If any Find Hub network accessory separated from its owner is seen moving with you over time, you'll be notified in one of two ways:

- ❶ If you have an Android device, Find Hub will send a notification to your device. This feature is available on Android 9 or later.
- ❷ If you don't have an Android device, a Find Hub network accessory that isn't with its owner for a period of time will emit a sound when it's moved. These features were created especially to discourage people from trying to track you without your knowledge.

4. Can I add/ setup multiple tags at the same time?

No. Only setup one tag at a time. Having multiple tags in pairing mode close by at the same time may result in delays or connecting an incorrect Smart Tag.

5. How long does connection take?

Times may vary between different devices and environments, 30 to 90 seconds is a normal guide of time.


6. Can I monitor more than one tag on the Find Hub app on my phone?

Yes, multiple Smart Tags can be located via your phone.

7. How is my privacy protected?

Only you can see the location of your smart Tag. Find Hub network uses advanced encryption to ensure that no one else, not even Google or the manufacturer, can view the location of your smart Tag.

Specifications

Device Name	Smart Tag
Battery	90mAh
Charging time	Approx. 3 hours
Standby time	Up to 4 months
Dust & Water resistance	IP64
Size	45.8x40.4x8.1mm
Rating	5V  0.09A

Regulatory safety information

Without permission, any company, firm or user shall not alter the frequency, increase the power, or change the characteristics and functions of the original design of the certified lower power frequency electric machinery.

The application of low power frequency electric machineries shall not affect the navigation safety nor interfere a legal communication, if an interference is found, the service will be suspended until improvement is made and the interference no longer exists. The foregoing legal communication refers to the wireless telecommunication operated according to the telecommunications laws and regulations. The low power frequency electric machinery should be able to tolerate the interference of the electric wave radiation electric machineries and equipment for legal communications or industrial and scientific applications.



Works with Android
Find Hub

The Find Hub network provides an easy, secure way to locate the Anko Rechargeable Smart Tag using the Find Hub App on your Android device.

To use the Find Hub App to locate this Rechargeable Smart Tag, the latest version of Android Operating Software is recommended.

MADE IN CHINA

CUSTOMER SERVICE:

KMART AU: 1800 124 125

KMART NZ: 0800 945 995

TARGET AU: 1300 753 567

FOR AU / NZ: IMPORTED FOR KMART
STORES IN AUSTRALIA AND NEW ZEALAND.

Android is a trademark of Google LLC.

Google, Android, and Find Hub are trademarks of Google LLC.



12 Month Warranty:

Thank you for your purchase.

Your new product is warranted to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law. For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

Contact for Kmart purchases	Contact for Target purchases
Kmart Australia Ltd. C/- Customer Service Centre 690 Springvale Road, Mulgrave Vic 3170 Customer Service: 1800 124 125 (Australia) or 0800 945 995 (New Zealand) or via Customer Help at kmart.com.au	Target Australia Pty Ltd C/- Customer Service Centre 2 Kendall Street, Williams Landing, Vic, 3027 Customer Service: 1300 753 567 or via Customer Help at target.com.au/help/contact-us