

REBOUND SLAM

Keycode:43621958

Warning:

- Do not stand on the product – Risk of falling or damage.
- **CHOKING HAZARD** - Small Parts. Not for children under 3 years.
- Adult assembly only.
- Do not aim at eyes or faces.
- Improper installation may reduce its function, and could reasonably result in the product to tip over and injuring children.

Accessories

- 1 x foldable rebounder
- 2 x wood padels
- 2 x pickleballs
- 3 x PVC balls
- 1 x pump
- 1 x carry bag



1. How to Assembly

Step 1: Unpack & Layout

(Please take care to keep your fingers clear when opening)



Place foldable rebounder from the carry bag on flat surface, hold both ends and extend outward.

Step 2: Release Buckle Adjust Details to Erect Rebounder



2.1 Simultaneously press both sides spring buckles downward then upward, make sure the pin locks into the hole.



2.2 Lock both sides with included pins



2.3 Tighten net tension using panel-mounted Velcros.
(Note: reflective strips are integrated into the Velcros alerts players in low-light situations.)

2. How to Play Rebound Slam

Rebound Slam is a fast-paced, outdoor game for two or more players. The aim is to hit the ball onto the net so your opponents can not return it. There are two ways to play.

Option 1: Padel Bat Mode

Use the padel bat and yellow pickleballs.

Hit the ball onto the net using the bat so it bounces up.

Opponents must return the ball before it touches the ground—within a maximum of 3 touches.

Option 2: Hand Ball Mode

Use the blue hand balls and hit the ball using your hand.

Gameplay is the same—serve and return the ball by bouncing it off the net.

Basic Rules (for both modes):

Serve by hitting the ball onto the net.

The other team has up to 3 touches to return it.

Play continues until the ball touches the ground or fails to hit the net.

Score a point when the opposing team fails to return.

Play to 11, 15, or 21 points—choose your own match rules.

Play with up to 4 players

3. Collapse & Storage

3.1 Release all Velcros (Step2-2.3)

3.2 Remove both sides pins (Step2-2.2)

3.3 Release all spring buckles, fold the legs inward (Step2-2.1)

3.4 Put rebounder upside-down as shown below.


Find out two protruding joints (red circles) and two flush joints (yellow circles).

Using the diagonal line between the red circled protruding joints as your axis,

apply simultaneous hand/foot pressure to all three arrow-marked positions

(1,2,3), then fold along the diagonal axis. (Green line)

Now, store all accessories in the carry bag.



MADE IN CHINA

CUSTOMER SERVICE:

KMART AU:1800 124 125

KMART NZ:0800 945 995

TARGET AU:1300 753 567