

<b>Jada</b>		<b>Final Output Approval</b> <small>(Hong Kong Office use only)</small>	
		Signature	Date of approval
Description: RC Instruction Sheet		Ant Dept Approved	
Scale: 1:18		Engineer Approved	
Material Code: M354-0001 (3/2018)		QA Engineer Approved	
Date: 08 Aug 2025		Remarks:	
Prepared By: Andy			

1/16" RC  
Size: 21mm x 297mm  
Front 1C + Back 1C

**INSTRUCTIONS SHEET MUST BE RETAINED SINCE IT CONTAINS IMPORTANT INFORMATION.**

These operating, installation, and safety instructions are integral parts of the product.

**IMPORTANT: Please read all "CONSUMER INFORMATION" before operating this toy vehicle. ADULT SUPERVISION REQUIRED.**

**Note to Adults:** To ensure that the child plays in both safe and fun, please review all operating instructions and safety notes in the CONSUMER INFORMATION section with your child.

**— CONSUMER INFORMATION —**

**CONTENTS:**

- 1 x Vehicle with Built-in Rechargeable Battery
- 1 x Transmitter Controller, 2 x AA Batteries

**SAFETY TIPS:**

- Toy surface may become hot and cause burns if the electronics get wet. Do NOT OPERATE this vehicle near/through water, snow, sand, grass or any wet or muddy surfaces.
- Never play the vehicle on asphalt. The streets are for real cars!
- Do not pick up vehicle while in motion.
- Always place the car gently on the floor by hand. Never throw the car onto the floor.
- Avoid collisions with walls, any hard objects, or furniture/bodies.
- Keep fingers, hair and loose clothing away from fans and wheels hubs.
- To avoid accidental operation, remove all batteries from controller when not in use.
- Do not connect this toy with other power supplies.
- Do not touch any live micro-electrical contacts.
- Be sure to test your vehicle for at least 5 minutes after every 15 minutes of operation.
- Stay clear of obstructions and hazards to avoid injury and damage.

**YOUR NEW RC IS DESIGNED WITH A BUILT-IN RECHARGEABLE BATTERY. CONTROLLER IS DESIGNED TO WORK WITH 2 AA BATTERIES.**

**WARNING:** Rechargeable battery is not replaceable.

**INSTALLING BATTERIES INTO CONTROLLER (See Diagram 2)**

- Press down the battery door and pull the battery compartment door open at the same time.
- Remove and properly dispose of the used batteries if any.
- Insert the 2 "AA" batteries with polarity (+/-) as shown inside battery compartment.
- Replace the battery compartment door.

**BATTERY SAFETY INFORMATION (CONTROLLER)**

- Do not mix alkaline, standard (carbon-zinc), or rechargeable batteries.
- Remove controller batteries if RC will not be used for a long period of time to prevent possible battery leakage.
- Dispose of batteries safely. Do not dispose of batteries or products containing non-rechargeable batteries in fire, as batteries may explode or leak.
- Rechargeable batteries are to be removed from the toy before being charged.
- Rechargeable batteries are to be charged by an adult only.
- Non-rechargeable batteries are not to be recharged.

- Different types of batteries or new and used batteries are never to be mixed.
- Batteries are to be inserted with the correct polarity.
- Exhausted batteries are to be removed from the toy.
- The supply terminals are never to be short-circuited.

**CAUTION: BUILT-IN BATTERY SAFETY INFORMATION**

- Carefully read the instruction guide and use the battery correctly.
- Built-in USB adapter is permanently attached to the vehicle. To protect your vehicle, only connect to USB certified port.
- Adult supervision is required when charging the vehicle.
- Never charge or store the vehicle in extremely hot or cold temperatures (about 104°F/40°C or below, 14°F/10°C, or beyond 60±25% relative humidity). Don't charge or store the vehicle toy inside a parked car under the sun.
- Keep USB cable enclosed inside the chassis to avoid fraying or during playing. DO NOT over extend or break the cable.
- Charge battery in isolated area. Keep away from flammable materials.
- Do not expose to direct sunlight.
- Do not recharge the toy if it is hot. Allow it to cool before recharge.
- Do not stop or subject to strong impacts.
- Do not allow the battery to get wet.
- In the unlikely event of leakage or explosion use sand or a chemical fire extinguisher for the battery.
- Rechargeable batteries are only to be charged under adult supervision.
- Routine examination for damage to the plug, enclosure and other parts. In the event of any damage, the toy must not be used with USB port until the damage has been repaired.
- This toy is not intended for children under 3 years old.
- Power supply shall be supplied at 5V ±5% VA.
- The power supply is not a toy.
- misuse of the power supply can cause electric shock.
- The toy shall only be used with a power supply for toys.
- The toy is only to be connected to Class I equipment bearing the following symbol:

**QUICK TIPS**

- The included rechargeable battery is not charged prior to shipment and must be charged before the first use.
- When your vehicle starts to lose power, it may lose function or performance. Its time to recharge the batteries. Your vehicle's running time may change depending on your driving style.
- Radio membrane can make your vehicle run abnormally. Interference can be caused by other R/C vehicles running on the same frequency, electrical wires, large buildings, or CB radios. Try to stay away from these.
- Point your transmitter controller antenna up – not down toward your vehicle. Your vehicle gets too far away, it won't work properly.
- Make sure your vehicle rear wheel is in direct sunlight. Always turn the switch to the off position when not in play.

**CLEANING INSTRUCTION**

To clean, wipe any dirt from the toy. Disconnect from power supply before wiping the toy with a moist tissue. DO NOT IMMERSE IN WATER and DO NOT CLEAN WITH ANY CHEMICALS. Let fully dry before use.

**INSTRUCTION FOR DISPOSAL OF WASTE**

- Your batteries and electronic toys should be recycled or disposed per your local waste management guidelines.
- Contact your local waste management officials for information regarding the environmentally sound recycling and disposal of batteries and electronic toys.

- FEATURES:**
- Up to 20 minutes playtime
  - 50 minutes quick charge
  - Full function RC
  - Custom r/m's and graphics
  - Turbo boost

**TROUBLE SHOOTING**

PROBLEM	SOLUTION
Vehicle does not respond to controls.	1. Transmitter controller battery is drained. Replace the controller battery. 2. Vehicle is out of range. Bring controller closer to the vehicle. 3. Interference from surrounding electrical machinery. Bring to a wide open space.
Vehicle does not drive straight.	Adjust the steering dial underneath the front side, left or right, until the wheels point straight / forward.
Vehicle does not move.	Stop operation, switch off the power and rest your vehicle a few minutes.
Vehicle does not respond properly.	Major reason is out of range. Bring controller closer to the vehicle. If problem still happen, remove the controller batteries and replace with new batteries and repair (DO NOT) fix the vehicle.
Transmitter controller does not work.	The controller light is off, its battery is drained. Replace the controller battery.

**Industry Canada Warning:**

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions: 1. This device may not cause interference. 2. This device must accept any interference, including interference that may cause undesired operation of the device.

Under Industry Canada regulations, this radio transmitter may only operate using an antenna of a type and maximum (or lesser) gain approved for the transmitter by Industry Canada. To reduce potential radio interference to other users, the antenna type and its gain should be so chosen that the equivalent isotropically radiated power (e.i.r.p.) is not more than that necessary for successful communication.

This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

**FCC WARNING:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

**Warning:** Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Electrical products should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority or retailer for recycling advice.  
Products with batteries should not be disposed of with household waste. Please recycle where facilities exist. Check with your local authority or retailer for recycling advice.



We reserve the right to improve or amend product specifications. Colors may vary. Jada oval mark is a registered trademark of Jada Toys, Inc.

©2025 JADA TOYS, INC. CITY OF INDUSTRY, CA 91748, USA


MADE IN INDONESIA

The product uses 2.4GHz remote control technology.



RF frequency band: 2411-2472 MHz  
Transmitter power: 0.765dBm

**CHARGING YOUR VEHICLE:**

1. Make sure the switch is in the ON/CHARGE position
2. Open the chassis door and pull out the USB charging cable
3. When plugged into a USB certified port, the light on the chassis will blink fast to indicate that the vehicle is charging.
4. Once the vehicle is finished charging, the light will stop fading and stay ON
5. Charging times will vary depending on what kind of port it is plugged into



**2 x "AA/LR6" Included**



**HOW TO PLAY:**

1. Turn the vehicle ON, then turn the transmitter controller ON within 17 seconds.  
\* Do not press any other buttons or switches on the controller while pairing, this may cause interference.
2. The LED on both the vehicle and controller will start blinking.
3. Once the pairing is successful, the LED on both the vehicle and controller will stop blinking and stay on.
4. If pairing is unsuccessful, turn the vehicle and controller OFF and try again.

- \* If your controller LED is blinking or losing brightness, please replace the battery.
- \* If your vehicle LED is blinking or losing brightness, please turn off and recharge the vehicle battery.
- \* When playing with multiple vehicles, only pair one controller to one vehicle at a time in order to avoid interference.

**TURBO BOOST FEATURE:**

- Press down the Turbo Button to increase the speed of the vehicle
- The light on the controller will flash quickly to indicate that the Turbo Boost is in use
- Release the Turbo Button to resume back to normal speed