

anko

Camera Glasses

Operating Instructions

Please read this manual carefully before using this product and retain it for future reference.

- Includes:
- 1 × Camera Glasses
 - 1 × 2-pin charging cable
 - 1 × Cleaning cloth
 - 1 x Eyeglass pouch
 - 1 x Instruction manual



K: 43700141 | T: 72420935
Model: JLR-82067

Product Specifications:


- Water Resistance: IPX4
Working distance: 10M (no obstacles)
Working time: approx. 3.5 hours at 80% volume
Charging Time: approx. 2 hours
Input: 5V – 200mA
Battery Capacity: 3.8V 290mAh rechargeable lithium-ion battery (non-replaceable)

Important Safety Information

- › This product contains a rechargeable lithium-ion battery (non-replaceable).
- › Do not leave the device connected to the charger for extended periods.
- › Avoid exposing the device to high temperatures or direct sunlight for prolonged periods.
- › Do not allow the battery to fully discharge before recharging.
- › Do not disassemble, crush, puncture, or modify the battery or device.
- › Handle with care and avoid strong impacts or dropping.
- › Do not leave the device unattended when charging.
- › Do not dispose of old batteries in household garbage. Dispose of the device and used batteries in accordance with local laws and regulations.
- › Wear your glasses correctly and

- adjust the temples and nosepiece to a comfortable position to avoid pressure on the bridge of the nose or ears.
- › Use a soft eyeglass cloth to wipe the lenses and avoid using alcohol or aggressive cleaning agents. Do not place your eyeglasses in a hot, humid or dusty environment.
 - › If you need to use with near-sighted lenses, please customize them through official channels to ensure accurate optical parameters.
 - › Use the original charger and data cable to avoid overcharging or over-discharging, and do not wear glasses when charging.
 - › When not in use for a long time, keep the device at about 50% battery level and store it in a dry environment.
 - › When using the photo, video or voice assistant, please abide by local laws and regulations and respect other people's privacy.
 - › Pay attention to the official release of the software update information in time, and follow the instructions to update, in order to get a better function experience and security. During the update process, make sure the device is fully charged and do not disconnect from the network.

Product Diagram



Download the App

Method 1:

Scan the QR code below to download and install the APP.



Method 2:


Download the “HeyCyan” app from the App Store or Google Play.

Importance: AI experienced service will be ended 6 months after the APP was connected and activated, if you want to keep using the AI service, it may be charged and charging standard would be updated in the APP. Other basic functions can be normal use, would not be affected.

Charging and Active

Fully charge the device before first use.

1. Align the magnetic charging cable with the charging contacts on the right temple of the glasses.
2. Ensure the connection is secure.
3. The indicator light will turn Red when charging and Blue when fully charged.



Connecting to your Phone

1. Enable Bluetooth on your smartphone.
2. Open the “HeyCyan” app. Tap "Connect Device". The app will automatically search for available devices.
3. Select "Anko43700141" from the list and tap "Connect" to pair.

Auto Reconnect: Once successfully paired, the glasses will automatically reconnect to your smartphone whenever they are within range and Bluetooth is enabled.



Operating Instructions

1. Power on:

Press and hold the front button for 2 seconds to power on the device. A power-on tone will be heard.

2. Power off:

Press and hold the front button for 5 seconds to power off the device. A shutdown tone will be heard.

Note: The device will automatically power off after 5 minutes if no Bluetooth connection is detected.

3. Take a photo:

Press the front button once to take a photo.

4. Video recording:

Double press the front button to start video recording. Press the front button once during recording to stop and save the video.

5. Audio Recording:

Press and hold the rear button to start audio recording. Press the rear button once during recording to stop and save the recording.

6. Calls:

- › Answer a call: Press the front button once
- › Reject a call: Double press the front button
- › End a call: Press the front button once during a call

7. AI image recognition & Voice Assistant

AI Image Recognition
Double press the rear button to activate AI image recognition.

Voice Assistant
Press the rear button once or use the voice command “Hey Cyan” to activate the voice assistant.

8. Music Control:

- › Play / Pause: Double tap the right touch area
- › Previous Track: Triple tap the right touch area
- › Next Track: Press and hold the right touch area
- › Volume Up: Swipe forward on the right touch area
- › Volume Down: Swipe backward on the right touch area

Wear Detection
Music will automatically pause when the glasses are removed.


9. Factory Reset:

Press and hold the front button for 10 seconds to restore factory settings.

10. Clear Bluetooth Pairing Records:

Triple press the rear button to clear pairing records between the glasses and the app.

LED indicator Description



1. Power On: The blue indicator light turns on for 1 second.
2. Power Off: The red indicator light turns on for 2 seconds.
3. App Connected: The blue indicator light turns off.
4. Disconnected: The blue indicator light flashes once every second.
5. Charging:
The red indicator light stays on during charging.
The blue indicator light stays on when fully charged.
6. Photo Capture: The left flash light turns on briefly, and the blue indicator flashes once.
7. Video Recording: The left flash light remains on, and the blue indicator light remains on.
8. AI Image Recognition: The left flash light flashes, and the blue indicator flashes once.
9. Voice Assistant: The blue indicator light flashes continuously.

12 Month Warranty

Thank you for your purchase.

Your new product is warrantied to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the

Australian Consumer Law.
For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.
We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty.
This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage.

You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth® SIG, inc.. and any use of such marks by KMART AUSTRALIA is under licence.

If you have any cybersecurity-related concerns or queries, please contact us online via our ‘Contact Us’ page at <https://www.kmart.com.au/contact-us/> or reach us by phone using the numbers listed below.



MADE IN CHINA
CUSTOMER SERVICE:
KMART AU: 1800 124 125
KMART NZ: 0800 945 995
TARGET AU: 1300 753 567



Statement of Compliance

Security standard for consumer grade relevant connectable products
AUSTRALIA

This statement of compliance has been prepared by, or on behalf of Kmart Australia Limited, who is the manufacturer of the below product. The statement of compliance is made in accordance with the Cyber Security (Security Standards for Smart Devices) Rules 2025, authorized by the Cyber Security Act 2024.

Product manufacturer details	
Name of the manufacturer	Kmart Australia Limited
Address of the manufacturer	1 Middle Rd, Chadstone VIC 3148
Name of the authorized representative	Jerry Or (Product Technologist)
Address of the authorized representative	Room 1016-1023A, 10/F, Trade Square, No. 681 Cheung Sha Wan Road, Cheung Sha Wan, Kowloon, Hong Kong
Name(s) of other authorized representatives in Australia (if applicable)	N/A
Address(es) of other authorized representatives in Australia (if applicable)	N/A
Product details	
Product type	CAMERA GLASSES
Batch identifier	43700141
Defined support period for the product	We will provide security updates for App until 4 March 2026. This device will receive all available security updates until 4 March 2026.

Declaration

It is declared that, in the opinion of the manufacturer:

1. The product listed in the table above has been manufactured in compliance with the requirements of Part 1 of Schedule 1 of the Cyber Security (Security Standards for Smart Devices) Rules 2025.
2. The manufacturer has complied with any other obligations relating to the product in Part 1 of Schedule 1 of the Cyber Security (Security Standards for Smart Devices) Rules 2025.

It is declared that this statement of compliance has been prepared by, or on behalf of, the manufacturer of the product listed in the table above and is accurate at the date of issue of 3 Mar 2026.

Prepared by or on behalf of Kmart Australia Limited

Jerry Or

3 Mar 2026

(Name, function and signature of the signatory of the manufacturer)

(Place and date of issue of the statement of compliance)

