

说明书材质：128g铜版纸
折叠尺寸55x78mm 双面印刷风琴折

anko

Instruction Manual



Sleep Pod Earbuds
K: 43-722-679 | T: 72-474-075

Made in China

Before use please read this manual carefully.
Please retain for future use.

1. Safety Instruction

- 1) Do not attempt to disassemble or replace any parts inside the product, except for the operation methods specially marked in the manual.
- 2) Do not put the product into water or any other liquid, as this product is not waterproof.
- 3) If any liquid accidentally gets inside the product, immediately disconnect it and remove the product.
- 4) To avoid electric shock, make sure your hands are dry when installing or uninstalling the product.
- 5) Do not place this product in an environment with strong electromagnetic force, otherwise, it may cause product failure. Disconnect and remove the product.
- 6) Adjust to a comfortable volume as high volumes may damage hearing.



Battery Warnings

- 1) Do not expose the product to any high temperatures over 60°C (like hair dryer, heating, prolonged sunlight etc.) The battery inside of the product may overheat and explode as a result.
- 2) Do not crush or pierce the battery! Do not expose the battery to high pressure, as this may cause an internal short-circuit and overheating.
- 3) This product contains batteries that are non-replaceable.
- 4) The product and the battery must not be taken apart, thrown into fire, immersed in liquids or short circuited.
- 5) Do not cover the product while charging the battery.
- 6) Charge the product in a well-ventilated environment.
- 7) Use only regulatory-compliant adapters for charging.

2. Package Contents

Earbuds x2
Charging case x1
USB-C charging cable x1
Instruction manual x1

3. Product Specifications

Bluetooth® Connection: ANKO43722679
Transmission Distance: 10-15 meters (in open space)
Charging Case Input: 5V 300mA
Charging Case Battery Capacity: 3.7V, 200mAh
Earbuds Battery Capacity: 3.7V, 25mAh
Bare Weight of Product: 32g
Charging Time: 1.5 hours for Earbuds
1-1.5 hours for Charging Case
Playing Time: 4-5 hours (80% Volume)

4. Product Overview



Functional touch area

indicator light

Earbuds



USB-C

Charging case

5. LED Indicators

Charging indicator light	Charging the earbuds but not fully charged	White lights stays on
	Earbuds fully charged	Light turns off
	Charging the charging case	Green light flashes
	Charging case fully charged	Green light stays on
	Charging case low on power	White light flashes
Earbud indicator light	Power on	White and blue lights flash alternately
	Power off	White light flashes 1 times
	Bluetooth pairing state	White and blue lights flash alternately
	Earbuds paired successfully	Light turns off

Note:

- > Charging the Charging Case Use a USB-C charging cable to connect the charging case to a 5V power adapter. This device does not support fast - charging heads.
- > When the White light of the charging case indicator flashes, please charge the charging case in time.

6. Product Operations Instructions

1) Power on

Method 1: Take the earbuds out of the charging case, and the earbuds will power on automatically.

Method 2: Long press 3 seconds to power on L/R single earbud when earbud is off state.

2) Power off

Method 1: Put the earbuds back into the charging case, and the earbuds will power off.

Method 2: Tap the function area of either earbud six times to power off the earbuds.


3) How to Pair with a Bluetooth Device

Step 1. Take the earbuds out of the charging case. The earbuds will power on automatically and White and Blue lights flash alternately.

Step 2: Open the Bluetooth list of your smart device. Search and select "ANKO43722679" from the list of found devices. Click to connect (supports single - earbud use).

Step 3: After paired successfully, the light turns off.

Step 4: When open the charging case and take out the two earbuds, it will automatically search for and attempt to connect with the last paired device "ANKO43722679".



7. Touch Button Control

Support gesture touch control, touch sensor area clicking. You can quickly adjust and convenient operation in one go.



Tap 2 times

Pause/Play for either earbuds
Answer/hang up call (incoming call)



Tap 3 times

L earbud for Previous track
R earbud for Next track



Tap 4 times

L earbud for Volume-
R earbud for Volume+



Long press 2 seconds

Reject call (incoming call)



Long press 3 seconds

power on L/R single earbud when earbud is off state
Activate voice assistant (except during a call) when earbud is on state

8. Trouble Shooting

1) Earbuds cannot be turned on/no response.

Ensure the charging case has power before placing the earbuds back in. Wait at least 15 minutes before attempting to remove them.

2) Unable to pair with phone/device.

After removing the earbuds, observe the earbud's breathing light. A flashing light indicates that it is pairing. Then, go to the Bluetooth devices list, find ANKO43722679, and click to connect.

3) Only one earbud can be connected/One earbud has sound while the other doesn't.

First, find Bluetooth name "ANKO43722679", on the Bluetooth function of your phone, tap to delete it. Place both earbuds back into the charging case, close the case lid, then open it again, take both earbuds out together, wait 5 seconds, and then search for and connect to "ANKO43722679" in the Bluetooth device list.

12 Month Warranty:

Thank you for your purchase.

Your new product is warranted to be free from defects in materials and workmanship for the period stated above, from the date of purchase, provided that the product is used in accordance with accompanying recommendations or instructions where provided. This warranty is in addition to your rights under the Australian Consumer Law. For New Zealand customers, this warranty is in addition to statutory rights observed under New Zealand legislation.

We will provide you with your choice of a refund, repair (where possible) or exchange (availability dependent) for this product if it becomes defective within the warranty period. The business will bear the reasonable expense of claiming the warranty. This warranty will no longer apply where the defect is a result of alteration, accident, misuse, abuse or neglect.

Please retain your receipt as proof of purchase and contact our Customer Service Centre as listed below, for the entity you purchased this product from, for any difficulties with your product. Warranty claims and claims for expense incurred in returning this product can be addressed to the respective Customer Service Centre.

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality and the failure does not amount to a major failure.

MADE IN CHINA



CUSTOMER SERVICE:

KMART AU: 1800 124 125

KMART NZ: 0800 945 995

TARGET AU: 1300 753 567

The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth® SIG, Inc., and any use of such marks by KMART AUSTRALIA is under licence.