


BACK COVER
8.5 cm



P3
8.5 cm

CARRYING BABY FACING TOWARDS YOU

Step 1:
Secure baby carrier without your baby by fastening the shoulder strap buckles (7), leg support button (8) and head support button (3). Put baby carrier on your back and breathe in deeply and attach the waist touch fastener (10) of the waist belt as tight as you can. Fasten the waist belt buckle (11) pull the strap until snug and pack up the overlong safety belt and turn to the front of you.

Step 2:
Place your baby in baby carrier towards you and adjust baby's sitting position, while securely holding your baby with one hand put on the shoulder strap (2) with your other hand. Swap hands and do the same for the other shoulder strap (2) while still holding the baby.

Step 3:
Reach behind your upper back and connect chest buckle (1). If necessary, tighten the strap until snug and/or adjust its height. Pull the shoulder straps down to tighten them until snug. Check head support button (3) to ensure baby's head is well supported. You can open the cool mesh zippers (6) and fold into the pocket underneath during summer season.

FRONT COVER
8.5 cm



P4
8.5 cm

CARRYING BABY FACING FORWARD

WARNING: This position should only be used for baby who can hold up his/her head unsupported (approximately 6 months old) and is tall enough for his/her head to be above the folded headrest. Follow the instructions as per steps 1, 2 and 3 on page 3. Place your baby facing away from you. Fold down the headrest (5), then connect the panel button (4).

CARRYING BABY ON THE BACK (6 months+)

Step 1:
Secure baby carrier without your baby by fastening the shoulder strap buckles (7), leg support button (8) and head support button (3). Put baby carrier on your back and breathe in deeply and attach the touch fastener of the waist belt as tight as you can. Fasten the waist belt buckle (11), pull the strap until snug and pack up the overlong safety belt.

Step 2:
With the help of a second person, place baby on baby carrier, then put the shoulder straps over your shoulders.

Step 3:
Fasten the chest buckle (1). If necessary, tighten the strap until snug and/or adjust its height. Pull the shoulder straps down to tighten them until snug.

P1
8.5 cm

WARNING!
This 3 Way Baby Carrier is designed to carry a baby between 8lb(3.6kg) and 33lb(15kg).
Read and follow all warnings and instructions before using this baby carrier. Never leave your child unattended inside the baby carrier.
When using the carrier, monitor your child.
Small children can slip through the leg openings.
Adjust the leg openings to fit child's legs snugly.
Child must face towards you until he/she can hold head upright (approximately 4-5 months old).
Hold your baby closely at all times until all the buckles are correctly attached. Ensure baby is properly positioned with legs straddling the baby pouch and both arms extended through the armholes.
Check that all buckles and adjustments are secured before each use. Take care when bending or leaning forward or sideways. Ensure that you are holding your child safely in your arms.
Always make sure there is enough room around your baby's nose and mouth to provide a clear source of air.
Never lay down with baby in the baby carrier.
Child must be able to sit upright unassisted to use the backpack position (about 6 months old).
Child must face forward, towards the caregiver in the backpack position. This carrier is not suitable for use during sporting activities.
Inspect the baby carrier for any signs of wear and tear.
Do not use this baby carrier if any parts are torn, damaged or missing. Your balance may be adversely affected by your movement and that of your child.
For low birthweight babies and children with medical conditions, please seek advice from a health professional before using the product.
Keep the baby and user away from heat sources or hot drinks.

P5
8.5 cm

REMOVING THE BABY FROM BABY CARRIER

REMOVING THE BABY FROM BABY CARRIER WITH FACING IN AND FORWARD POSITIONS:
It is recommended that you remove your baby from Baby Carrier while sitting.

Step 1:
Hold your baby safely with one hand. Using your free hand, release the back chest buckle (1) and slip off the shoulder strap. Do the same for the other shoulder. At all times, ensure your baby is held safely in your arms.

Step 2:
Remove the baby from the baby carrier then release the waist belt buckle (11).

REMOVING THE BABY FROM BABY CARRIER WITH BACKPACK POSITIONS:

Step 1:
With the help of a second person holding your baby, release the chest buckle (1) and slide both shoulder straps (2).

Step 2:
Remove the baby from baby carrier and release the waist belt buckle (11).

P2
8.5 cm

List of Components:

- (1) Chest Buckle
- (2) Shoulder Straps
- (3) Head Support Button
- (4) Panel Button
- (5) Headrest
- (6) Cool Mesh Zippers
- (7) Shoulder Strap Buckles
- (8) Leg Support Button
- (9) Waist Belt
- (10) Waist Touch Fastener
- (11) Waist Belt buckle

CONFORMS TO EN13209-2:2015

P6
8.5 cm

CARE AND MAINTENANCE

To extend the life and integrity of the baby carrier, we recommend that regular care be limited to spot cleaning with a damp cloth.
Machine wash only if necessary.
Machine wash separately in cold water, gentle cycle. Do not use fabric softener.
Do not bleach.
Drip dry.
Do not iron.
Do not dryclean ☹.

IMPORTED BY
© KIMART AUSTRALIA LIMITED
2860, RIVERSIDE AND BENT SOUTHWAY ARE TRADEMARKS OF KIMART AUSTRALIA LIMITED. THEY ARE USED IN NEW ZEALAND BY KIMART NZ HOLDINGS LIMITED TRADING AS KIMART IN NEW ZEALAND.
KIMART AUSTRALIA - 400 SPRINGDALE ROAD, MILLERSIDE, VIC 3070 AUSTRALIA
KIMART NEW ZEALAND - REGIONAL OFFICE C/O KIMART PARROTSHOPE STORE, HUNTERS PLACE, GREAT SOUTH ROAD, INVERCOTE, AUCKLAND, NEW ZEALAND.
Kagazide 42-770-662
MADE IN CHINA