>>> INSTRUCTION MANUAL










SAVE THESE INSTRUCTIONS. READ COMPLETE INSTRUCTIONS BEFORE USE.


1. How to bind

- 1. Turn on the vehicle first, then turn on the transmitter.
- When the light of the transmitter is flashing, that means it's matching.
- 3. If the light is on and not flashing, that means they are matched.
- 4.If it doesn't complete the binding process within 8 seconds, please turn off both the vehicle and transmitter and re-start the binding process.
- 5. When the binding process is complete, whenever you switch the vehicle and transmitter on and off, it searches for the memorised code and will only lock onto the transmitter signal containing that code.
- 6.If you have more than two vehicles, please bind them one by one. When the second vehicle is binding, always keep the first vehicle and transmitter on.
- 7.Please turn off both the vehicle and transmitter and re-start the binding process if you are changing to another 2.4GHZ transmitter.


2. How to play


Switch ON the vehicle and transmitter.







2.Use the steering wheel to control the vehicle turning left or right






Use the accelerator trigger to drive the vehicle forwards, stop, or backwards







- 4. Play on a smooth surface for optimum performance
- 5. Remember to switch OFF the power of the Vehicle and Transmitter after playing
- 6. The optimum control range is up to 30 metres outdoors


Disposal of batteries



Batteries should not be disposed of in the household waste. As the consumer you are legally obliged to return batteries containing harmful substances and all other used batteries. You can hand in your old batteries at public collection points in your area or wherever batteries are sold. You will find these chemical abbreviations along with a crossed-out refuse bin on batteries containing harmful substances:

Pb=Battery contains lead Cd=Battery contains cadmium Hg=Battery contains mercury


3. Battery charge and installation instructions





Computer charging only

Charging time: 4 - 5 hours Playing time: 10 - 15 minutes



Transmitter battery installation instruction

- 1. Switch off the transmitter
- 2. Unscrew to open the battery compartment
- 3. Insert 2 x AA batteries into the correct + and polarities
- 4. Close the cover

Vehicle battery charge instruction

- Unscrew to open battery compartment.
- 2. Please switch the vehicle to "CHARGE" before charging.
- 3. Plug the USB charging cable into USB port.
- The indicator will be flashed when charging. The indicator will be off when charging is finished.
- 4. Unplug charging cable and close the battery compartment after charging.

Attention: Do not charge battery immediately after each play. Let the battery cool down for a while.

Cautions

- 1. The charger to be used with the toy should be regularly examined for potential hazard, such as damage to the cable or cord, plug, enclosure of other parts and that in the event of such damage, the toy must not be used until that damage had been properly removed.
- 2.Do not attempt to disassemble the vehicle or transmitter
- 3. Do not operate the vehicle with the same frequency as other player(s) in the same location as this will interfere and make the vehicle go out control.
- 4. Make sure the batteries are installed with correct polarities (+/-)as shown inside the battery compartment
- 5. Remove the package and take out all accessories before giving the Vehicle and Transmitter to a child to play with

The packaging and instruction manual contains important information. Please keep them for future reference.

Warning! Choking Hazard. Not suitable for children under the age of 3 years due to small parts. We reserve the right to improve/amend specifications and colours without notice.

SAFETY PRECAUTIONS

Do not operate during thunderstorms or rain.

Avoid water, sand and snow when operating the car.

Do not submerge car or controller in water.

Never operate your car on the street or highway

Never operate your car in a confined or crowded area and do not use people or animals as obstacles.

Do not run your car into furniture, objects or hard surfaces, as this will cause damage to both the objects and the car.

Keep fingers, hair and loose clothing away from the tires, gears and motor while the car is switched to "ON".

Do not leave the car or transmitter near sources of heat or under direct sunlight for long periods of time. Do not leave the car or transmitter outside overnight. Dampness is harmful to interior components.

Remove all batteries when not in use to avoid accidental operation

Adult supervision is recommended when operating this car.

BATTERY WARNING:

Do not mix old and new batteries.

Do not mix alkaline, standard(carbon-zinc), or rechargeable (nickel—cadmium)batteries.

Insert batteries using the correct polarity. Do not short-circuit the supply terminal.

Remove batteries when not in use. Recycle or dispose of exhausted batteries according to federal, state. And local laws.

Do not dispose of batteries in afire-they may leak or explode.

Only use manufacture specified battery(ies), charger(s) and/or adapter, if applicable, specified by the manufacturer.

Always use, replace, and recharge(if applicable) batteries under adult supervision.

Non-rechargeable batteries are not to be recharged:

Rechargeable batteries are to be removed from the for before being charged;

Rechargeable batteries are only lo be charged under adult supervision;

Exhausted batteries are to be removed from the toy; The supply terminals are not to be short-circuited.

Packaging has lo be kept since it contains important information.


Product may vary slightly from image shown

Performance Tips: Do not drive the vehicle on grass, sand rocks or go through water.

Do not drive the vehicle into any hard object.

The battery charger used with the electric toy shall be regularly examined for damage to the supply cord, plug, enclosure or other parts, and in the event of damage, it shall not be used until the damage has been repaired.

The vehicle contains batteries that are non-replaceable.



1/16

SCALE