


# Instruction Manual


Read the following instructions carefully before using the lounger:

**Step 1** - Lay lounger upside down.




**Step 2** - Pull legs outward until locked

**Tip** - Pull the legs outward until they lock into place.  
- You'll know they are locked when they do not easily fold back or close.




**Step 3** - Flip the lounger over and set it on the legs.


**WARNING**- Make sure the legs are fully extended and locked. They should be angled outward before use.





**Step 4**-Unbuckle the straps.



**Step 5**- Open the head and foot sections fully until they lay flat. Then, rotate the latch downward to lock them in place.



**Step 6** - Raise the head section until it locks in position. To adjust to a different position, fully lower it before raising again.



## CAUTION:

1. Lounger holds maximum of 100kgs.
2. Keep fingers away from hinged areas of lounger.
3. Make sure the legs are fully extended and locked.
4. Only use with one person at a time.
5. Avoid sitting on either end. Only sit on the middle section.

297 mm

210 mm